



After Hours Air-Conditioning Instructions

Owen Dixon Chambers West Levels 1 to 18



The zone thermostat (as shown below) is located in the common area on each floor.

To start the air-conditioning;

1. Press the  button once
2. The run time in minutes will be displayed
3. Press the  button to increase the run time
4. The green LED light will illuminate to indicate the system is on
5. The time remaining in minutes will be displayed in the bottom left hand corner



To end air-conditioning;

1. Press the  button once
2. Press the  button until the time is reduced to 0 min
3. The green light will then switch of

