## **Customising your Handset.**

**Handset volume**: With handpiece at ear press + or – keys (13 on diagram)

**Speaker volume:** While on loudspeaker press + or – keys (13 on diagram)

**Adjust contrast:** While handset is idle press + or – keys (13 on diagram)

**Programming keys:** From **Perso** page on screen select a blank key [ ....]. Press

*Speed Dial* soft key to program a number or *Services* to program a function, make changes then press *Apply*.

**To modify** a programmed key press information **1** key followed by key in question, select *Modify*, make changes

& press Apply or press Delete to delete.

**Change ring tone:** From **Menu** page select *Settings, Phone, Ringing*. Select

Internal or External, select tone & press ( to apply

### Initialising your Voice Mail Box (if allocated).

 Access Voice mail by pressing Mail Services key then Voice mail soft key

- 2. When prompted enter password (default 120000)
- 3. Follow prompts to change password and record mail box name
- 4. To record personal greeting, from main menu select option 4, then option 2, record after tone, press # to end, then follow prompts.
- 5. To activate personal greeting press \* to return to main menu then select option 6
- 6. Once your voice mail box is initialized, set preferred diversions to voice mail.

## **Accessing Voice Mail messages**

1. Press Mail services key then press Voice Mail soft key

2. Press new voice message notification key then follow prompts

**NB:** To access messages remotely dial **9225 8989**, enter 4 digit extension then follow prompts.



# **8028s Handset Quick Reference Guide**



1. LED incoming call indicator

2. Black & white screen

3. Programmable Keys

4. Navigation keys

Back/Exit

Mail Services

7. Information key

8. Redial

9. Handsfree/Loudspeaker

10. Dial by Name keyboard


11. Volume up/down

12. Headset jack

13. Mute key

14 End call key

#### Welcome Screen:



Menu: Contains options for customising

handset

**Perso:** Contains line & programmable keys

(default home page)

**Info:** Displays handset status including

extension name & number

## **Navigator Keys:**



**OK:** Applies changes when configuring or programming

Left-Right navigator: Used to move from one page to another

**Up-Down navigator:** Scrolls through content of current page

**Back/Exit:** Short press to previous page, long press to exit & return

to default screen (Perso)

## Screen Displays:

Incoming Call

**\_** 

On hold



**Call in Progress** 

Make call: Internal - Dial 4 digit extension

External - Dial 0 (or 35) for outside line followed by

desired number

NB: Prefix 0 suppresses your caller ID while prefix 35

displays it

**Answer incoming call:** Lift handset or press Handsfree/Loudspeaker key

**End call:** Press End call button or return handpiece to cradle

**Answer second call:** Press Incoming Call soft key. Original caller is

automatically placed on hold and you are connected to

second caller.

Place call on hold: Press Call in Progress soft key. To return to caller press On

Hold soft key or press *Retrieve* soft key.

Mute: Press Mute \( \subseteq \text{ key to activate; press again to deactivate} \)

**Transfer call**: Press *New call* soft key, dial destination number & when ready

to transfer press *Transfer* soft key

**Retrieve call:** To cancel transfer (if extension is busy, does not reply etc.)

press Enquiry Off soft key

**Conference call:** With 2<sup>nd</sup> party on line press *New call* soft key, dial 3<sup>rd</sup> party &

when ready to connect, scroll down to & press *Confer* soft key. For 4<sup>th</sup> & subsequent parties press *Add* soft key, dial number &

when answered press *Insert* soft key

**Redial:** Short press to redial last number & long press to

display list of last 8 numbers dialed

**Divert call:** Press soft key, select type of diversion required

(immediate, busy etc) & dial destination number

**Divert to Voicemail:** Press soft key, to divert straight to voicemail select *Imm* 

fwd VM. For busy &/or no answer select Other fwd, Forward

on busy/no reply then Voice msg

Cancel Diversion: Press Soft key & select Deactivate soft key

**Dial by Name:** Type in person's name (surname, first name or initials), select

relevant search type on screen (ie. name, initials, etc.) then

press key alongside name to call

**Call log**: Contains last 50 calls made & received, internal & external.

Press Mail Services key then *Call Log* soft key. Upward arrow indicates outgoing call, downward arrow indicates incoming call, circle represents answered call, cross represents unanswered call. Press respective soft key then *Recall* to call

or *Delete/Delete All* to remove from log.